Extract Competence Bauwerk

8.4 CARE OIL MATRIX

for nature oiled Bauwerk parquet

| | Oak | Oak black limed | Oak slightly smoked | Oak Nuvola | Oak Roccia | Oak Avorio | Oak Farina | Oak smoked Farina | Oak Avena | Oak Caffelatte | Oak Creta | Oak Fango used-look | Oak slightly smoked Canneto | Oak Sasso | Oak Silver | Oak Deserto used-look | Oak slightly smoked Cacao | Oak Ambra | Oak Fumo | Oak Gold | Oak Mandorla | Oak Tabacco used-look | Oak slightly smoked Terra | Oak smoked Lava | Oak smoked | Acacia steamed | Cherry American | Walnut American | Oak Caffè | Oak Caramello | Oak Fulvo |
|--------------|-----|-------------------|---------------------|--------------|--------------|--------------|--------------|---------------------|-------------|------------------|-------------|-----------------------|-------------------------------|-------------|--------------|-------------------------|-----------------------------|-------------|------------|------------|----------------|-------------------------|-----------------------------|-------------------|--------------|----------------|-----------------|-----------------|-------------|-----------------|-------------|
| Colourless | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| White | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | ı | |
| Beige | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Grey | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Light brown | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Golden brown | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Brown | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Black | | | | | | | | | | | | | | | | | | | | | | | | | \bigotimes | \bigotimes | | \bigotimes | | | |

available as Care oil

available as Care oil and Care oil Plus

Alternative: colours more intense than brown

Alternatively you can use the solvent-free Bauwerk Care Oil Eco. Use Care Oil Eco white for Farina surfaces and colourless Care oil for all other surfaces.

A simple test can show whether or not natural-oiled parquet is sufficiently protected: Pour some water onto the surface. If the water forms compact droplets, the surface in that area is sufficiently saturated with oil.

